

REF.2537 MDS DIGITAL DESKTOP GUARD UNIT

Technology Guides >> MDS Equipment



For MDS Digital systems. These can be combined with other types of systems such as MDS Direct, MDS City and ADS. The MDS DIGITAL system can simultaneously manage multiple guard services. These can act as basic guard units, or building's administration centres or as panic call reception centres (where they act as guards and their function is to receive alarm warnings generated once a panic button has been pressed. This is incorporated into the telephone itself or a monitor installed in the residence, or in another location within the home). One sole guard unit can carry out both functions.

During normal operation, calls made from any access panel to the building are received by the Central Guard Unit, allowing the guard to advise the relevant resident of the visit, pass him/her the call, or deal with it personally. The Central Guard Unit can also work in what is called mixed mode, during which visitors' calls are received by the corresponding residence, but it is possible to call the guard directly with any queries, telephone number for a particular residence etc. On the other hand, the Central Guard Unit also receives calls from residents who wish to speak to the guard. If the guard is not available when a call is received, the call will be recorded (up to a total of 20) and he can respond to them on his return. The guard may also connect 2 residents, on one of their requests. Description of the image. 1- Display: Offers a range of information when using the Central Guard Unit. 2- Search Keys: Press the arrows to locate the name of the resident you wish to call. Start the search by pressing the right arrow. 3- Call Key (bell: To call residential telephones or other guard units. 4- Operation Keys: - Door opener: Door opener activation key. - Guard Communication - Telephone: Activate the communication channel between the GUARD UNIT and the last TELEPHONE called. - Panel Communication - Telephone: Activate the communication channel between the PANEL and the last TELEPHONE called. - Guard Communication - Panel: Activate the communication channel between the GUARD UNIT and the last PANEL to be called. - Guard Communication - Panel Decoder: Activate the communication channel between the GUARD UNIT and the Panel connected to the PANEL DECODER selected via the keypad. - Residential Communication- Residence: Activate the communication channel between two residences. 5- Data Keypad. Located below the telephone receiver. It is used to enter the telephone number of the residence you wish to call, check calls waiting, enter and check data in general. It is also used to programme residential terminals as if it were a panel.

Availability**Additional information**Size of product when packed: **29x26x24.5 cm**Weight: **2,400 Kg**EAN13: **8424299025377**



FERMAX ELECTRONICA, S.A.E.
EXPORT DEPARTMENT
Avda. Tres Cruces, 133
46017 VALENCIA (Spain)

Phone 34 96 317 80 11
Fax 34 96 378 84 02
e.mail export@fermax.com
web www.fermax.com



FERMAX - CIF A-46036554 - Avda Tres Cruces, 133 - 46017 Valencia - +34 96 3178011 -